

FIG. 1




FIG. 2




FIG. 3



81 82 83	CALL FROM DESTINATION DEVICE	CALL FROM SOURCE DEVICE
	SOURCE DEVICE NUMBER	DESTINATION DEVICE NUMBER
	RECORD NUMBER OF STARTING EXTENT	CYLINDER ADDRESS OF DESTINATION DEVICE
	RECORD NUMBER OF ENDING EXTENT	HEAD IDENTIFIER OF DESTINATION DEVICE

FIG. 4




FIG. 5



HA CONTROLLER 86

DA CONTROLLER 88




FIG. 6




FIG. 7




FIG. 8





WRITE  
OPERATION  
FROM SOURCE  
HOST





FIG. 9



READ OR WRITE  
OPERATION FROM  
DESTINATION HOST





REQUESTING HOST APPLICATION

DATA STORAGE FACILITY 24




FIG. 11




FIG. 12




FIG. 13




FIG. 14



REQUESTING HOST APPLICATION

DATA STORAGE FACILITY 24




FIG. 15